

Hugostudio List of Available Camera Covers

SLR

Asahiflex IIB

Canon A-1
Canon AE-1
Canon AE-1 Program
Canon AV-1
Canon Power Winder A
Canon EF
Canon F-1
Canon F-1n (New)
Canon FT
Canon FTb n
Canonflex
Canon TL-QL

Contax 137 MA
Contax 137 MD
Contax 139 Quartz
Contax139 Quartz Winder
Contax RTS
Contax RTS II
Conax Motor Drive W6

Edixa Reflex D

Exakta A Type I
Exakta A Type 4.1 Sun/Moom Logo
Exakta VP Version 1,2 & 3
Exakta VX IIa W/ P2.2 Finder
Exakta VX IIa W/ P3.3 Finder (1960)
Exakta VX IIb W/ P4 Finder
Exakta VX 1000 W/ P4 Finder
Exakta VX 500 W/ H3.3 Finder
Exakta Varex VX W/ Finder P1
Exakta Finder: prism P2
Exakta Finder: prism P3
Exakta Finder: prism P4
Exakta Finder H3
Exakta Meter Finder
Exa Version I
Exa Version 2 to 5
Exa Version 6
Exa Ia, Ib
Exa II
Exakta 500

Fujica AZ-1
Fujica AX-3
Fujica ST 701
Fujica ST 801
Fujica ST 901

Konica FT-1
Konica T3

Konica T4
Konica TC

Minolta SRT 100
Minolta SRT 101
Minolta SRT 202
Minolta X570
Minolta X700
Minolta Motor Drive 1
Minolta Auto Winder D
Minolta Auto Winder G
Minolta XE-7
Minolta XG7, XG-E, XG 9,
Minolta XD 11, XD 5, XD 7, XD
Minolta XM

Miranda AII (1957)
Miranda Sensorex

Nikommat
Nikkormat FT, FTn
Nikkormat FT 2, FT 3
Nikon 35 Ti
Nikon F W/ Eye Level Finder
Nikon F W/ Photomic FTn
Nikon F2 W/ DP1
Nikon F3 HP
Nikon FA
Nikon FE
Nikon FE2
Nikon FG
Nikon FG20
Nikon EM
Nikon FM
Nikon FM 2n
Nikon Motor Drive MD-4

Olympus OM-1
Olympus OM-2
Olympus OM-2S Program
Olympus OM-4
Olympus OM-10

Pentax K1000
Pentax LX
Pentax KX
Pentax ME Super
Pentax Spomatic SP
Pentax Spomatic SP 1000
Pentax Spomatic SP 500
Pentax Spomatic SPII
Pentax Spomatic S1a

Praktica FX, Praktiflex FX
Praktica Super TL
Praktiflex

Rolleiflex SL35E

Topcon Super D

Zeiss Ikon Contaflex S-Matic
Zeiss Ikon Icarex 35S

Yashica FX-3
Yashica FX-D Quartz
Yashica FX-D SE Quartz

RANGEFINDER / VIEWFINDER

Acarelle 1954-55 (1960?)

Aires 35 V
Aires 35 III, IIIa, IIIb
Aires 35 IIIc
Aires 35 III L

Argus C
Argus C "F-S" Shutter speed range switch
Argus C2 - Back w/ 3 strips no ASA dial
Argus C2 - W/ 3 strips & ASA dial
Argus C3 - Back w/ 3 strips no ASA dial (Pre War)
Argus C3 - Back w/ 3 strips no ASA dial without front logo (Pre War)
Argus C3 Standard - W/3 strips & ASA dial (Pre War)
Argus C3 - Back w/3 strips no ASA dial (Post War)
Argus C3 Standard - W/3 strips & ASA dial (Post War)
Argus C3 - Solid one strip back
Argus C3 Pre War front cover is about 1mm bigger compare to C3 made after the War (1946)
Please check what year your C3 was made before ordering
Argus C4
Argus Mark Finder M-21

Berning Robot II

Bolsey Model C

Eho-Altissa Classic 35

Foth Derby Type 3

Graflex: Graphic 35

Kodak Retina Automatic III
Kodak Retinette 1b
Kodak Retina Reflex S
Kodak Retina Reflex III, IV
Kodak 35
Kodak Signet 35

Konica I
Konica III

Kiev 4A

Leica I Model a
Leica I Model c
Leica If
Leica IIf

Leica III
Leica IIIa
Leica IIIa (No strap lugs)
Leica IIIc
Leica IIIf (No self timer)
Leica IIIf With Self Timer
Leica IIIg
Leica M Early Back Door Cover
Leica M Late Back Door Cover
Leica M1
Leica M2
Leica M2 (No self timer)
Leica M3 SS (Round Strap Lugs)
Leica M3 DS (Buddha ears)
Leica M3 (Buddha ears) No viewfinder, no frame pre-selector lever
Leica M4
Leica M4-2
Leica M5
Leica Standard E

Leotax K

Lordox 24x36

Mamiya 35 I, 35 II, 35 III & 35 S

Mercury Univex CC Without adhesive
Mercury II CX Without adhesive

Minolta A
Minolta 35 Model II
Minolta 35 Model II Large Front Panels

Nikon S
Nikon S2

Kuribayashi Petri Semi (1948)

Perfex Thirty-Three

Ricoh 35
Ricoh 500

Sanei Samoca 35 III

Tower Type 3

Voigtlander Vitessa
Voigtlander Vito B
Voigtlander Prominent
voigtlander Perkeo II
Voigtländer Vitessa T (Type 136)

Wirgin Edixa Flex (1958)
Wirgin Edinex (Early Version) W/Plate on the back
Wirgin Edinex II

Yamato Pax I (Not listed)

Yashica 1c Lynx 14E

Yashica Electro 35
Yashica Electro 35 GSN
Yashica Electro 35 GT

Zeiss Ikon Contax I
Zeiss Ikon Contax IIa
Zeiss Ikon Ikonta 520/15
Zeiss Ikon Ikonta 521
Zeiss Ikon Ikonta 524/16
Zeiss Ikon Super Ikonta 530/16
Zeiss Ikon Super Ikonta 531
Zeiss Ikon Super Ikonta 531/16
Zeiss Ikon Super Ikonta 5334/16
Zeiss Ikon Super Ikonta 534/16
Zeiss Ikon Tenax I
Zeiss Ikon Tenax Automatic

Zorki 4

SMALL 35MM / MINIATURE

Brown Super II

Braun Carl Super Paxette II

Canon Canonet 28
Canon Canonet QL17
Canon Canonet QL17 GIII QL
Canon Canonet QL19

Kodak Bantam
Kodak Flash Bantam

Konica C35
Konica 3S

Mikroma
Olympus 35 ED
Olympus 35 RC
Olympus Pen D
Olympus Pen EE
Olympus Pen EES-2
Olympus Pen EE-3
Olympus Pen F
Olympus Pen S
Olympus Trip 35
Olimpus Pen E PL1

Roico

Rollei 35

TLR / MEDIUM FORMAT

Autofifty

Ciroflex B
Ciroflex D
Ciroflex E

Flexaret IIa

Ikoflex Coffe Can
Ikoflex IIa

Hasselblad 500C
Hasselblad 500CM

Kiew 88
Kiew 88 Film Back
Kiew 88 TTL Prism

Kodak Medalist
Kodak Medalist II

Mamiyaflex C
Mamiyaflex C2
Mamiya C220
Mamiya C3
Mamiya C33
Mamiya C330
Mamiya C330 f
Mamiya C330 s
Mamiya 645
Mamiyaflex Automat A
Mamiya 23 Press
Mamiya Super 23
Mamiya Universal Press

Minolta Autocord I
Minolta Autocord RGV1
Minolta Autocord RGV1 – V3

Pentacon Six TL

Pentax 6X7
Pentax 645

Welta Reflekta I

Rolleicor Ia
Rolleicord IIb Model 3
Rolleicord IIc
Rolleicord-II Model 1K3
Rolleicor II Phillips
Rolleicord III
Rolleicord III Type 2
Rolleicord V
Rolleiflex 2.8 D
Rolleiflex 2.8E
Rolleiflex 2.8E2
Rolleiflex 2.8 GX Viewfinder (only)
Rolleiflex Automat II
Rolleiflex Automat III
Rolleiflex 3.5A Model 4 K4A
Rolleiflex 3.5B Type2
Rollei Magic I
Rolleiflex Old Standard 622
Rolleiflex SL 66

Salut 6x6

Voigtlander Brilliant

Yashica 12
Yashica 24
Yashica 44
Yashica 44 LM
Yashica 635
Yashica A (Back Panel Screw Holes 46mm)
Yashica A (Back Panel Screw Holes 50.4mm)
Yashicaflex A Late Version
Yashica B
Yashica C
Yashica D
Yashica Mat
Yashica Mat 124
Yashica Mat 124G
Yashica Mat LM
Yashica Pigeonflex Ib
Yashica Rookie

Zenza Bronica ETRS
Zenza Bronica SQ-Ai
Zenza Bronica SQ-A
Zenza Bronica Funnel Panel

Zorki 88

MOVIE CAMERAS

Bolex Paillard B8

LIGHT SEALS KITS